



**CAN COLLECT**  
DIRT, DUST & SMALL DEBRIS (DRY USE ONLY)

**CAN'T COLLECT**  
ANYTHING WET, HAZARDOUS OR THAT WILL GET WRAPPED  
AROUND THE BRUSH (STRING, BANDING, SHRINKWRAP ETC.)

**HOW IT WORKS**  
THE MAIN ROLLER BRUSH CONCEALED UNDERNEATH THE  
MACHINE REMOVES THE DIRT FROM THE FLOOR  
IN BOTH FORWARD & REVERSE




**FRONT/SIDE BRUSH**  
**IS FOR EDGE CLEANING ONLY**  
HAVE THIS OFF THE FLOOR THE REST OF  
THE TIME



**WHERE DOES THE DIRT GO?**  
IN THE FRONT & REAR CONTAINERS – REMOVE TO EMPTY

**IS THERE A FILTER?**  
YES, THE POLYESTER CARTRIDGE FILTER RETAINS SMALL  
PARTICLES OF DUST – REMOVE & CLEAN AFTER USE



**HOW LONG WILL IT RUN FOR?**  
UNLIMITED RUNNING TIME  
(MANUAL SWEEPER = NOT BATTERY POWERED)

**CAN I ADJUST THE BRUSH PRESSURE?**  
EASILY ADJUST THE MAIN BRUSH TO SUIT  
THE TYPE OR FLOOR & DEBRIS YOU ARE COLLECTING  
**(DO NOT OVERTIGHTEN)**

**CALL 0141 647 4200 FOR ASSISTANCE**



- This notice serves as a quick guide to important points to remember
- The machine should be used by authorised trained operators only
- All operators must read & understand the operator manual prior to use



**SCAN ME**

### **BEFORE USE**

- Check brushes
- Check rubber flaps
- Check filter
- **Check container(s) are empty**

### **OPERATION**

- **Ensure side brush is off the floor**
- Adjust main brush to suit the floor type – brush should just touch the floor
- Push to activate (also works in reverse)
  
- Side brush can be put down to sweep edges / sides / under pallets etc.
- Go **slow** for most effective sweeping of edges / sides / under pallets etc.
  
- **You should NOT see dust when using this sweeper** – if you can see dust, something needs attention e.g. check the side brush is up / the filter is clean / the bin is empty

### **AFTER USE**

- **Empty containers**
- **Check brushes**
- Check rubber flaps
- **Check filter**
- Wipe machine down with damp cloth

### **DO NOT**

- **DO NOT** collect string, banding, shrink-wrap or similar this will cause serious damage to the machine
- **DO NOT** operate sweeper with side brush continually on floor, this will cause dust to become airborne

**CALL 0141 647 4200 FOR ASSISTANCE**